



# Formulation

Name	<b>HIP N' TIGHT FIRMING SHEET MASK SOLUTION</b>	
No.	1313	
Description	Reach for this firming and tightening sheet mask solution when your face needs a pick-me-up. Enriched with rosehip and algae extracts, this mask solution may provide an instant tightening effect while AMPHOSOL® 2CSF-AF gently cleanses and removes excess oil.	
Formulation	<b>INGREDIENTS:</b>	<b><u>% by Weight</u>   <u>Functionality</u></b>
	=== Phase 1 ===	
	Deionized Water	90.10 Carrier
	Glycerin	2.00 Humectant
	AMPHOSOL® 2CSF-AF	5.00 Foaming & Mild Cleansing Agent
	PEPHA®-TIGHT (DSM) Algae Extract and Pullulan	1.00 Active, Skin Feel
	Rosehip Extract #3329GL (Bio-Botanica) Rose Canina (Rosehip) Extract	0.25 Additive
	=== Phase 2 ===	
	STEPANTEX® CO-40	1.00 Solubilizer
	Apricot Plumeria Rose Fragrance #EE19-33561 (Premiere Specialties)	0.60 Fragrance
	=== Phase 3 ===	
	Citric Acid, 10% Solution	q.s. pH Adjuster
	Preservative	q.s. Preservative
	<b>Total</b>	<b>100.00</b>
Procedure	<ol style="list-style-type: none"> <li>1. Charge Deionized Water into kettle.</li> <li>2. Add Glycerin, AMPHOSOL® 2CSF-AF, PEPHA®-TIGHT and Rosehip Extract Fragrance #3329GL one at a time with mixing between each addition.</li> <li>3. Pre-mix STEPANTEX® CO-40 and Apricot Plumeria Rose Fragrance #EE19-33561 until soluble. Add to batch.</li> <li>4. Adjust pH to 5.5-6.5 with Citric Acid, 10% Solution and Preservative as needed.</li> </ol>	
Physical Properties	Appearance, as is	Clear liquid
	pH, as is	6.0
Storage/Stability	4 weeks at 25°C	Stable
	4 weeks at 40°C	Stable
	4 weeks at 5°C	Stable
	Freeze/Thaw, 3 cycles	Pass
Instructions for Use	Use with cellulose-based sheet mask. Apply to face 10-15 minutes. Remove mask and rinse face thoroughly.	
Registered Trademarks of Stepan Company	AMPHOSOL® STEPANTEX®	

For  
Additional  
Assistance

For applications or product handling assistance, call our Technical Service Department at 1-800-745-7837 (U.S.) or 011-334-76-505-100 (Europe).  
For ordering assistance, call our Account Service Department at 1-800-457-7673.

The information contained herein is based on the manufacturer's own study and the works of others and is subject to change without prior notice. The information is not intended to be all-inclusive, including as to the manner and conditions of use, handling, storage or disposal or other factors that may involve additional legal, environmental, safety or performance considerations. Nothing contained herein grants or extends a license, express or implied, in connection with any patents issued or pending of the manufacturer or others, or shall be construed as a recommendation to infringe any patents. **STEPAN COMPANY MAKES NO PRODUCT WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR USE, EXPRESS OR IMPLIED, AND NO OTHER WARRANTY OR GUARANTY, EXPRESS OR IMPLIED, IS MADE, INCLUDING AS TO INFORMATION REGARDING PERFORMANCE, SAFETY, SUITABILITY, STABILITY, ACCURACY, COMPLETENESS, OR ADEQUACY.** Stepan Company (and its employees, subsidiaries and affiliates) shall not be liable (regardless of fault) to the vendee, its employees, or any other party for any direct, indirect, special or consequential damages arising out of or in connection with the accuracy, completeness, adequacy, furnishing, use, or reliance upon information provided herein. The vendee assumes and releases Stepan Company (and its employees, subsidiaries and affiliates) from all liability, whether in tort, contract or otherwise to the fullest extent possible under the relevant law.



Stepan Company  
Northfield, Illinois 60093  
Telephone (847) 446-7500

Revision Date: 04/30/2019    Publication Date: 04/30/2019    © 2019, Stepan Company. All rights reserved.